

NOTES:

- ① FLOORS TO FALL TOWARDS PAN.
- ② DOOR TO HAVE 100mm CLEARANCE GAP FROM FLOOR.
- ③ BOTH FOOT-STEPS TO FALL TOWARDS PAN.
- ④ WHEN SITTING IN TOILET - TAP TO BE ON RIGHT HAND SIDE AND DOOR HUNG ON LEFT SIDE.
- ⑤ HANDRAIL ABOVE TAP.

LOW PAN
TOILET

SCALE 1:20

